



Two horizontal pieces are cut to a length that is 4 in. shorter than the horizontal measurement of the mirror.



Hold the cutting blade low and keep it perpendicular to the surface so your cut goes straight into the acrylic.



Use the edge of the 1x6 for bending along the score line. Push downward with a crisp snapping motion.



Grasp the waste end with a pliers if there is a short piece to snap off. Bend away from the scored surface.



Keep the dab of adhesive small and away from edges. It dries quickly, so place the strip immediately.



For the horizontal strips, apply a second layer of tape to compensate for the thickness of the mirror's fasteners.



Be sure the edges and ends are in the correct position before contacting the mirror. Once on, the strip cannot be adjusted.



Place two squares of tape and two dabs of adhesive to the back of each corner plate, avoiding the area of the gaps between the two strips.



The corner pieces add a finishing and decorative touch. They also hide the 1/2-in. gaps at the ends of the acrylic strips.